


# **P602 – Quad Redundant Gigabit Ethernet XMC**



*Configuration example*

*User Manual*

## **P602 - Quad Redundant Gigabit Ethernet XMC**

The P602 is a Gigabit Ethernet XMC mezzanine card suitable for any XMC compliant single-board computer or host carrier board in any type of bus system, i.e. CPCI, VME or on any type of stand-alone SBC. Compared to PMC, the XMC standard defines a different board-to-board connector for support of PCI Express®.

The four Ethernet channels on the P602 are provided by two Ethernet controllers with two lines each. Each of the two XMC connectors supports one link with up to four lanes. With a specific set-up the two lines inside each Ethernet controller can be used as a redundant channel pair. In this mode one line is monitored by the other line and the controller recognizes when an error occurs.

The P602 is typically suited as an extension for Windows® and Linux based systems with a heavy demand for multiple and ultra-fast communication requirements. As such it is used in high-bandwidth multi-channel communication applications in networked appliances such as base stations, routers, switches, gateways, residential gateway controllers, etc. Main target markets comprise telecom, medical engineering and transportation.

For use in rugged environments the mezzanine module P602 is delivered with a passive heat sink and is prepared for conformal coating. Equipped with Intel® components that come exclusively from the Intel® Embedded Line, the P602 has a guaranteed minimum standard availability of 5 years.

## Technical Data

### **Ethernet**

---

- Four 10/100/1000Base-T Ethernet channels at front panel
- RJ45 connectors at front panel
- Two independent dual-port Ethernet controllers
  - Fully integrated Gigabit Ethernet Media Access Controllers (MAC) and physical layer ports (PHY)
  - 48kB per port on-chip packet buffer
  - Full duplex and half duplex operation
- Ethernet controllers are connected by two PCIe® links with four lanes each
- Two LEDs per channel to signal LAN Link, Activity status and connection speed (10/100/1000Base-T)

### **XMC Characteristics**

---

- Compliant with XMC standard VITA 42.3-200x
- XMC connectors P15 and P16 assembled

### **Peripheral Connections**

---

- Via front panel on four RJ45 connectors

### **PCI Express®**

---

- Two links with four lanes each to connect local 1000Base-T Ethernet controllers (1GB/s per channel in each direction)
- One link with four lanes on XMC connector P15 and one on P16

### **Electrical Specifications**

---

- Isolation voltage: 1.5kV DC electrical isolation between isolated side and digital side
- Supply voltage/power consumption:
  - +5V or +12V (-5%/+5%), 1.4A typ. (+5V), 600mA typ. (+12V)
  - +3.3V (-5%/+5%), 100mA typ.
- MTBF: 920,841h @ 40°C according to IEC/TR 62380 (RDF 2000)

### **Mechanical Specifications**

---

- Dimensions: conforming to XMC standard VITA 42.0-200x
- Weight: 106 g (with heat sink)

### **Environmental Specifications**

---

- Temperature range (operation):
  - 0..+55°C
  - Industrial temperature range on request
  - Airflow: min. 10m<sup>3</sup>/h
- Temperature range (storage): -40..+85°C
- Relative humidity (operation): max. 95% non-condensing
- Relative humidity (storage): max. 95% non-condensing
- Altitude: -300m to + 3,000m
- Shock: 15g/11ms
- Bump: 10g/16ms
- Vibration (sinusoidal): 2g/10..150Hz
- Conformal coating on request

### **Safety**

---

- PCB manufactured with a flammability rating of 94V-0 by UL recognized manufacturers

### **EMC**

---


- Tested according to EN 55022 (radio disturbance), IEC1000-4-2 (ESD) and IEC1000-4-4 (burst)

### **Software Support**

---

- Drivers from Intel® for Windows® and Linux

# Block Diagram



## Product Safety



### Electrostatic Discharge (ESD)

Computer boards and components contain electrostatic sensitive devices. Electrostatic discharge (ESD) can damage components. To protect the board and other components against damage from static electricity, you should follow some precautions whenever you work on your computer.

- Power down and unplug your computer system when working on the inside.
- Hold components by the edges and try not to touch the IC chips, leads, or circuitry.
- Use a grounded wrist strap before handling computer components.
- Place components on a grounded antistatic pad or on the bag that came with the component whenever the components are separated from the system.
- Store the board only in its original ESD-protected packaging. Retain the original packaging in case you need to return the board to MEN for repair.

## About this Document

This user manual is intended only for system developers and integrators, it is not intended for end users.

It describes the hardware functions of the board, connection of peripheral devices and integration into a system. It also provides additional information for special applications and configurations of the board.

The manual does not include detailed information on individual components (data sheets etc.). A list of literature is given in the appendix.

### History

Issue	Comments	Date
E1	First edition	2008-04-23
E2	Corrected <a href="#">Chapter 3.1 Power Supply on page 18</a>	2012-03-02

### Conventions



This sign marks important notes or warnings concerning the use of voltages which can lead to serious damage to your health and also cause damage or destruction of the component.



This sign marks important notes or warnings concerning proper functionality of the product described in this document. You should read them in any case.

*italics*

Folder, file and function names are printed in *italics*.

**bold**

**Bold** type is used for emphasis.

monospace

A monospaced font type is used for hexadecimal numbers, listings, C function descriptions or wherever appropriate. Hexadecimal numbers are preceded by "0x".

*comment*

Comments embedded into coding examples are shown in green color.

hyperlink

Hyperlinks are printed in blue color.



The globe will show you where [hyperlinks](#) lead directly to the Internet, so you can look for the latest information online.

IRQ#  
/IRQ

Signal names followed by "#" or preceded by a slash ("/") indicate that this signal is either active low or that it becomes active at a falling edge.

in/out

Signal directions in signal mnemonics tables generally refer to the corresponding board or component, "in" meaning "to the board or component", "out" meaning "coming from it".



Vertical lines on the outer margin signal technical changes to the previous issue of the document.

## Legal Information

### Changes

MEN Mikro Elektronik GmbH ("MEN") reserves the right to make changes without further notice to any products herein.

### Warranty, Guarantee, Liability

MEN makes no warranty, representation or guarantee of any kind regarding the suitability of its products for any particular purpose, nor does MEN assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including, without limitation, consequential or incidental damages. TO THE EXTENT APPLICABLE, SPECIFICALLY EXCLUDED ARE ANY IMPLIED WARRANTIES ARISING BY OPERATION OF LAW, CUSTOM OR USAGE, INCLUDING WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR USE. In no event shall MEN be liable for more than the contract price for the products in question. If buyer does not notify MEN in writing within the foregoing warranty period, MEN shall have no liability or obligation to buyer hereunder.

The publication is provided on the terms and understanding that:

1. MEN is not responsible for the results of any actions taken on the basis of information in the publication, nor for any error in or omission from the publication; and
2. MEN is not engaged in rendering technical or other advice or services.

MEN expressly disclaims all and any liability and responsibility to any person, whether a reader of the publication or not, in respect of anything, and of the consequences of anything, done or omitted to be done by any such person in reliance, whether wholly or partially, on the whole or any part of the contents of the publication.

### Conditions for Use, Field of Application

The correct function of MEN products in mission-critical and life-critical applications is limited to the environmental specification given for each product in the technical user manual. The correct function of MEN products under extended environmental conditions is limited to the individual requirement specification and subsequent validation documents for each product for the applicable use case and has to be agreed upon in writing by MEN and the customer. Should the customer purchase or use MEN products for any unintended or unauthorized application, the customer shall indemnify and hold MEN and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim or personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that MEN was negligent regarding the design or manufacture of the part. In no case is MEN liable for the correct function of the technical installation where MEN products are a part of.

### Trademarks

All products or services mentioned in this publication are identified by the trademarks, service marks, or product names as designated by the companies which market those products. The trademarks and registered trademarks are held by the companies producing them. Inquiries concerning such trademarks should be made directly to those companies.

### Conformity

MEN products are not ready-made products for end users. They are tested according to the standards given in the Technical Data and thus enable you to achieve certification of the product according to the standards applicable in your field of application.



## **RoHS**

Since July 1, 2006 all MEN standard products comply with RoHS legislation.

Since January 2005 the SMD and manual soldering processes at MEN have already been completely lead-free. Between June 2004 and June 30, 2006 MEN's selected component suppliers have changed delivery to RoHS-compliant parts. During this period any change and status was traceable through the MEN ERP system and the boards gradually became RoHS-compliant.



## **WEEE Application**

The WEEE directive does not apply to fixed industrial plants and tools. The compliance is the responsibility of the company which puts the product on the market, as defined in the directive; components and sub-assemblies are not subject to product compliance.

In other words: Since MEN does not deliver ready-made products to end users, the WEEE directive is not applicable for MEN. Users are nevertheless recommended to properly recycle all electronic boards which have passed their life cycle.

Nevertheless, MEN is registered as a manufacturer in Germany. The registration number can be provided on request.

Copyright © 2012 MEN Mikro Elektronik GmbH. All rights reserved.

### **Germany**

MEN Mikro Elektronik GmbH  
Neuwieder Straße 3-7  
90411 Nuremberg  
Phone +49-911-99 33 5-0  
Fax +49-911-99 33 5-901  
E-mail [info@men.de](mailto:info@men.de)  
[www.men.de](http://www.men.de)

### **France**

MEN Mikro Elektronik SA  
18, rue René Cassin  
ZA de la Châtelaine  
74240 Gaillard  
Phone +33 (0) 450-955-312  
Fax +33 (0) 450-955-211  
E-mail [info@men-france.fr](mailto:info@men-france.fr)  
[www.men-france.fr](http://www.men-france.fr)

### **USA**

MEN Micro, Inc.  
24 North Main Street  
Ambler, PA 19002  
Phone (215) 542-9575  
Fax (215) 542-9577  
E-mail [sales@menmicro.com](mailto:sales@menmicro.com)  
[www.menmicro.com](http://www.menmicro.com)

# Contents

<b>1</b>	<b>Getting Started</b>	<b>13</b>
1.1	Map of the Board	13
1.2	Integrating the Board into a System	13
1.3	Installing Driver Software	13
<b>2</b>	<b>Connecting the XMC</b>	<b>14</b>
2.1	Peripheral Interfaces	14
2.2	Host PCI Interface	15
<b>3</b>	<b>Functional Description</b>	<b>18</b>
3.1	Power Supply	18
3.2	Ethernet Interfaces	18
3.2.1	Ethernet Controller	18
3.2.2	Thermal Considerations	19
<b>4</b>	<b>Appendix</b>	<b>20</b>
4.1	Literature and Web Resources	20
4.1.1	XMC	20
4.1.2	PCI Express	20
4.2	Finding out the Board's Article Number, Revision and Serial Number	20

---

## Figures

- Figure 1. Map of the board—front panel and top view . . . . . 13
- Figure 2. Labels giving the board’s article number, revision and serial number. 20

---

## Tables


Table 1.	Status LEDs of 8-pin RJ45 Ethernet 10/100/1000Base-T connectors (LAN_A..LAN_D) .....	14
Table 2.	Pin assignment of 8-pin RJ45 Ethernet 10/100/1000Base-T connectors (LAN_A..LAN_D) .....	14
Table 3.	Signal mnemonics of Ethernet 10/100/1000Base-T connectors.....	14
Table 4.	Pin assignment of 114-pin XMC connector P15 .....	15
Table 5.	Pin assignment of 114-pin XMC connector P16 .....	16
Table 6.	Signal mnemonics of 114-pin XMC connector .....	17

# 1 Getting Started

This chapter gives an overview of the board and some hints for first installation in a system.

## 1.1 Map of the Board

**Figure 1.** Map of the board—front panel and top view



## 1.2 Integrating the Board into a System

You can use the following "check list" to install the XMC on a carrier board for the first time and to test proper functioning of the board.

- Power-down the system and remove the XMC carrier board.
- Install the XMC in a suitable slot of the carrier board as described in the carrier board's user manual.
- Insert the carrier board into the system again.
- Power-up the system.
- If there is a system crash or other abnormal behavior at start-up, check if the XMC is plugged properly.
- You can now install driver software for the P602.

## 1.3 Installing Driver Software

For a detailed description on how to install driver software please refer to the respective documentation.



You can find any driver software available for download on MEN's [website](#).

## 2 Connecting the XMC

### 2.1 Peripheral Interfaces

You can connect peripherals via the four RJ45 Ethernet front connectors.

There are two status LEDs for each channel at the front panel which signal LAN link, activity status and connection speed. They are assigned to the four connectors in the following way.

**Table 1.** Status LEDs of 8-pin RJ45 Ethernet 10/100/1000Base-T connectors (LAN\_A..LAN\_D)

<p>Green LED: On: Link 100Mbps/s Off: Link with 10Mbps/s or 1000Mbps/s</p>	
<p>Orange LED: Blinks whenever there is transmit or receive activity</p>	

**Table 2.** Pin assignment of 8-pin RJ45 Ethernet 10/100/1000Base-T connectors (LAN\_A..LAN\_D)

		1000Base-T	10/100Base-T
	1	BI_DA+	TX+
	2	BI_DA-	TX-
	3	BI_DB+	RX+
	4	BI_DC+	-
	5	BI_DC-	-
	6	BI_DB-	RX-
	7	BI_DD+	-
	8	BI_DD-	-

**Table 3.** Signal mnemonics of Ethernet 10/100/1000Base-T connectors

Signal	Direction	Function
BI_Dx+/-	in/out	Differential pairs of data lines for 1000Base-T
RX+/-	in	Differential pair of receive data lines for 10/100Base-T
TX+/-	out	Differential pair of transmit data lines for 10/100Base-T

Connector types:

- Modular 8/8-pin mounting jack according to FCC68
- Mating connector:  
Modular 8/8-pin plug according to FCC68

## 2.2 Host PCI Interface

The P602 supports one PCI Express link with four lanes on each of the two XMC connectors.


In the following you find the pin assignment of the 114-pin XMC plug connectors P15 and P16:

**Table 4.** Pin assignment of 114-pin XMC connector P15

	F	E	D	C	B	A
1	VPWR	PET0n1	PET0p1	+3.3V	PET0n0	PET0p0
2	MRSTI#	GND	GND	-	GND	GND
3	VPWR	PET0n3	PET0p3	+3.3V	PET0n2	PET0p2
4	MRSTO#	GND	GND	TCK	GND	GND
5	VPWR	-	-	+3.3V	-	-
6	-	GND	GND	TMS	GND	GND
7	VPWR	-	-	+3.3V	-	-
8	-	GND	GND	TDI	GND	GND
9	VPWR	-	-	-	-	-
10	GA0	GND	GND	TDO	GND	GND
11	VPWR	PER0n1	PER0p1	-	PER0n0	PER0p0
12	MPRESENT#	GND	GND	GA1	GND	GND
13	VPWR	PER0n3	PER0p3	-	PER0n2	PER0p2
14	MSDA	GND	GND	GA2	GND	GND
15	VPWR	-	-	-	-	-
16	MSCL	GND	GND	MVMRO	GND	GND
17	-	-	-	-	-	-
18	-	GND	GND	-	GND	GND
19	-	-	WAKE0#	-	REFCLK-0	REFCLK+0

**Table 5.** Pin assignment of 114-pin XMC connector P16

	F	E	D	C	B	A
1	VPWR	PET1n1	PET1p1	+3.3V	PET1n0	PET1p0
2	MRSTI#	GND	GND	-	GND	GND
3	VPWR	PET1n3	PET1p3	+3.3V	PET1n2	PET1p2
4	MRSTO#	GND	GND	TCK	GND	GND
5	VPWR	-	-	+3.3V	-	-
6	-	GND	GND	TMS	GND	GND
7	VPWR	-	-	+3.3V	-	-
8	-	GND	GND	TDI	GND	GND
9	VPWR	-	-	-	-	-
10	GA0	GND	GND	TDO	GND	GND
11	VPWR	PER1n1	PER1p1	-	PER1n0	PER1p0
12	MPRESENT#	GND	GND	GA1	GND	GND
13	VPWR	PER1n3	PER1p3	-	PER1n2	PER1p2
14	MSDA	GND	GND	GA2	GND	GND
15	VPWR	-	-	-	-	-
16	MSCL	GND	GND	MVMRO	GND	GND
17	-	-	-	-	-	-
18	-	GND	GND	-	GND	GND
19	-	-	-	-	REFCLK-0	REFCLK+0



Connector:

- 114-pin XMC plug connector, e. g. SAMTEC :ASP105885-01
- Mating connector:  
114-pin XMC receptacle connector



**Table 6.** Signal mnemonics of 114-pin XMC connector

	Signal	Direction	Function
<b>Power</b>	VPWR	in	Variable power pins, +5V or 12V supply voltage
	+3.3V	in	+3.3V supply voltage
	GND	-	Ground
<b>PCI Express Link 0</b>	PER0p/n[0..3]	in	PCI Express link 0, differential receive, lanes 0..3
	PET0p/n[0..3]	out	PCI Express link 0, differential transmit, lanes 0..3
	REFCLK+/-0	in	Differential reference clock
	WAKE#	in	Reactivation of power rails and reference clocks
<b>PCI Express Link 1</b>	PER1p/n[0..3]	in	PCI Express link 1, differential receive, lanes 0..3
	PET1p/n[0..3]	out	PCI Express link 1, differential transmit, lanes 0..3
	REFCLK+/-0	in	Differential reference clock
<b>Other</b>	GA[0..2]	in	I2C channel select
	MSCL	in	IPMI I2C serial clock
	MPRESENT#	out	Module present
	MRSTI#	in	XMC reset in
	MRSTO#	out	XMC reset out
	MSDA	in/out	IPMI I2C serial data
	MVMRO	in	XMC write prohibit

## 3 Functional Description

### 3.1 Power Supply

The P602 is supplied via the carrier board. There are two supply voltages needed: 3.3V and VPWR. VPWR must be 5V or 12V.

The input currents at the P15 XMC connector are 1.4A ( $\pm 10\%$ ) with VPWR at 5V or 0.6A ( $\pm 10\%$ ) with VPWR at 12V. 100mA ( $\pm 10\%$ ) are consumed at 3.3V.

A wide range switching power supply generates the Ethernet controller supply voltages. These voltages have a value of 1.8V with a current of 2.2A ( $\pm 10\%$ ) and 1.1V with a current of 2.2A ( $\pm 10\%$ ).

### 3.2 Ethernet Interfaces

The P602 is equipped with two dual port gigabit Ethernet controllers and with a PCI Express interface according to the XMC standard.

#### 3.2.1 Ethernet Controller

The P602 is equipped with the Intel 82571EB Ethernet Controller. It is a single, compact component with two fully integrated Gigabit Ethernet Media Access Controllers (MAC) and physical layer ports (PHY). The device uses the PCI Express architecture.

The Intel 82571EB provides a standard IEEE 802.3 Ethernet interface for 1000Base-T, 100Base-TX, and 10Base-T applications (802.3, 802.3u and 802.3ab).

The Gigabit Ethernet Controller with PCI Express architecture is designed for high performance and low memory latency. The device is optimized to connect to a system using four PCI express lanes (x4 PCI Express interface). Alternatively the controller can use one PCI Express lane.

Wide internal data paths eliminate performance bottlenecks by efficiently handling large address and data words.

A large 48kB per port on-chip packet buffer maintains superior performance. In addition, using hardware acceleration, the controller offloads tasks from the host, such as TCP/UDP/IP checksum calculations and TCP segmentation.

The controller can be used in redundancy mode for high availability, reliability and safety.

In addition it provides a Serializer-Deserializer (SerDes) for optical fiber and backplane applications as well as SMB and FML management ports for support of a Board Management Controller (BMC).

### **3.2.2 Thermal Considerations**

The P602 Ethernet controllers are equipped with an extra heat sink which is fastened on the top side with three screws.



Note: MEN gives no warranty on functionality and reliability of the P602 if you use any other heat sink than that supplied by MEN. Please contact either MEN directly or your local MEN sales office!

## 4 Appendix

### 4.1 Literature and Web Resources

- P602 data sheet with up-to-date information and documentation:  
[www.men.de](http://www.men.de)

#### 4.1.1 XMC

- XMC PCI Express Protocol Layer Standard  
VITA 42.3-2006; June 2006  
VMEbus International Trade Association  
[www.vita.com](http://www.vita.com)
- Standard for VITA 42.0 XMC  
VITA 42.0-2008; December 2008  
VMEbus International Trade Association  
[www.vita.com](http://www.vita.com)

#### 4.1.2 PCI Express

- PCI Special Interest Group  
[www.pcisig.com](http://www.pcisig.com)

### 4.2 Finding out the Board's Article Number, Revision and Serial Number


MEN user documentation may describe several different models and/or hardware revisions of the P602. You can find information on the article number, the board revision and the serial number on two labels attached to the board.

- **Article number:** Gives the board's family and model. This is also MEN's ordering number. To be complete it must have 9 characters.
- **Revision number:** Gives the hardware revision of the board.
- **Serial number:** Unique identification assigned during production.

If you need support, you should communicate these numbers to MEN.

**Figure 2.** Labels giving the board's article number, revision and serial number

Complete article number



Revision number



Serial number